




Universal 8" Wrist Brace IFU




1. Insert hand into brace.




2. Position the bottom front edge of the brace below the palmer crease.




3. Position the top front edge of the brace behind the M.P. Joints.




4. Pull the strap snugly.




5. If necessary, detach and position the adjustable anchor to the center of the wrist.



6. Gently pull the hook thumb strap through webspace and attach it to the brace.



7. Wrap the hook lace strap securely around the brace.




8. Final application

NOTE: Do not over tighten. For best results, adjust the strap a second time to ensure a comfortable fit or continue to adjust as necessary.

CAUTION: If swelling increases and pain, numbness, skin irritation occurs, discontinue use. Contact medical provider immediately. This product is only a support device, not to prevent injuries or prevent preoccurrence of injuries.



OvationMedical® 

 5155 Clareton Dr.
Agoura Hills, CA. 91301
USA
800 403-6466
www.ovationmed.com

MDSS GmbH
Schiffgraben 41
30175 Hannover
Germany